



5411 Seymour Hwy Wichita Falls, TX 76301

Tel: 940-767-7694 Fax: 940-687-0751

WWW.NITROUSEXPRESS.COM

Caution – EXTREME DANGER – Caution

Do not use or mix any other manufacturer's products with any Nitrous Express products.

Do not use or mix any Nitrous Express products with any other manufacturer's products.

THESE INSTRUCTIONS APPLY TO NITROUS EXPRESS PRODUCTS ONLY!

FOR SANCTIONED RACE USE ONLY - NOT FOR SALE OR USE IN CALIFORNIA

NX BILLET FUEL PRESSURE REGULATOR, NON BYPASS

Parts Included:

1 Fuel Pressure Regulator

1 Bracket

Specifications:

Port Thread sizes: 3/8" NPT and 1/8" NPT gauge port

Adjustment range: 1.5-11psi

Fuel Compatibility: Gasoline, Alcohol/Methanol, and E-85

Installation:

1. Install fittings (3/8" NPT) into the regulator with NX Thread Sealer or Teflon Paste.
2. The fuel supply will connect at the port on the bottom of the regulator.
3. Connect the fuel line to the regulator.
4. Once all fittings and hoses are connected and all open/unused fuel ports have been plugged turn on the fuel pump and check for leaks. If leaks are found on the NPT (tapered) fittings, make sure the threads are covered properly with NX Thread Sealer or Teflon Paste.
5. Set the Fuel pressure. Loosen the jam nut on the top of the regulator and turn the adjustment screw to adjust the pressure. (Clockwise increases pressure)

NOTE: Fuel pressure must be set while fuel is **FLOWING THROUGH** the regulator; otherwise the regulator will continuously build pressure.

